Ref. Certif. No.

SE-111806

IEC SYSTEM FOR MUTUAL RECOGNITION OF TEST CERTIFICATES FOR ELECTRICAL EQUIPMENT (IECEE) CB SCHEME

CB TEST CERTIFICATE

Product	ICT/ITE Power Supply
Name and address of the applicant	GlobTek, Inc. 186 Veterans Drive Northvale NJ 07647, USA
Name and address of the manufacturer	Same as applicant
Name and address of the factory Note: *When more than one factory, please report on page 2*	☒ Additional Information on page 2
Ratings and principal characteristics	Input: 100-240V~, 50-60Hz or 50/60Hz; GT*96600-****, GT*91099-*****: 1.5A, Output: 5-54Vdc, Max. 8.00A, Max. 65W; GT*96600-*56***: 2.0A, Output: 56VDC, Max. 70W
Trademark / Brand (if any)	GlobTek, Inc.
Customer's Testing Facility (CTF) Stage used	-
Model / Type Ref.	GT*96600-****, GT*91099-*****, GT*96600-*56***
Additional information (if necessary may also be reported on page 2)	☒ Additional Information on page 2-3
A sample of the product was tested and found to be in conformity with	IEC 62368-1:2018
As shown in the Test Report Ref. No. which forms part of this Certificate	230302606SHA-001

This CB Test Certificate is issued by the National Certification Body

Intertek Semko AB
Torshamnsgatan 43
Box 1103
SE-164 22 Kista, Sweden

intertek

Date: 11 August, 2023

Signature:

Hyden Li

Factories

1. GlobTek, Inc.
186 Veterans Drive Northvale NJ 07647, USA

2. GlobTek (Suzhou) Co., Ltd
Building 4, No. 76 JinLing East Road, Suzhou Industrial Park, Suzhou, JiangSu, 215021, China

3. Shenzhen ENG Electronics Co., Ltd.
Block B, Nuclear Group Industrial District, Baishixia, Fuyun Town, Bao'an, Shenzhen, China

Additional information

Explanation of model GT*96600-****:
The 1st "*" part can be 'M' or '-' or 'H' for market identification and not related to safety.
The 2nd "*" denotes the rated output wattage designation, which can be "01" to "65", with interval of 1.
The 3rd "*" denote the standard rated output voltage designation, which can be "05" to "54" or "5.0" to "54.0" in 0.1V increments.
The 4th "*" =-T2 means desktop class II with C8 AC inlet
=-T2A means desktop class II with C18 AC inlet
=-T3 means desktop class I or class II with functional earth with C14 AC inlet
=-T3A means desktop class I or class II with functional earth with C6 AC inlet
=-T2L means desktop class II with C8 AC inlet and housing with a DC jack
=-T2AL means desktop class II with C18 AC inlet and housing with a DC jack
=-T3L means desktop class I or class II with functional earth with C14 AC inlet and housing with a DC jack
=-T3AL means desktop class I or class II with functional earth with C6 AC inlet and housing with a DC jack
=-R2 means hybrid desktop housing class II with C8 AC inlet
=-R3A means hybrid desktop housing class I or class II with functional earth with C6 AC inlet
=-F means Open Frame class I or class II with functional earth
=-FW means Open Frame class II
=-P2 means Encapsulated class II
=-P3 means Encapsulated class I or class II with functional earth
=-TP means desktop class II with power supply cord with plug
=-TP3 means desktop class I or class II with functional earth with power supply cord with plug
=-TW means desktop class II with input wire without plug
=-TW3 means desktop class I or class II with functional earth with input wire without plug
The last "*" denote any six character = 0-9 or A-Z or ()[] or – or blank for marketing purposes.

Explanation of model GT*91099-*****:
The 1st "*" part can be 'M' or '-' or 'H' for market identification and not related to safety.
The 2nd "*" denotes the rated output wattage designation, which can be "01" to "60", in step of 1 denote 1W.
The 3rd "*" denotes the standard rated output voltage designation, which can be "09", "15", "24", "48".
The 4th "*"is optional deviation, subtracted from standard output voltage, which can be "-0.01" to "-23.9" with interval of 0.01, or blank to indicate no voltage different.
The 5th "*" =-T2 means desktop class II with C8 AC inlet
=-T2A means desktop class II with C8 AC inlet
=-T3 means desktop class I or class II with functional earth with C14 AC inlet
=-T3A means desktop class I or class II with functional earth with C6 AC inlet
=-F means Open Frame class I or class II with functional earth
=-FW means Open Frame class II
=-P2 means Encapsulated class II
=-P3 means Encapsulated class I or class II with functional earth
The last "*" denote any six character = 0-9 or A-Z or ()[] or – or blank for marketing purposes.

Date: 11 August, 2023

Signature:

Explanation of model GT*96600-*56***:
The 1st "*" part can be 'M' or '-' or 'H' for market identification and not related to safety.
The 2nd "*" denotes the rated output wattage designation, which can be "01" to "70", with interval of 1.
The 3rd "*" =-T2 means desktop class II with C8 AC inlet
=-T2A means desktop class II with C18 AC inlet
=-T3 means desktop class I or class II with functional earth with C14 AC inlet
=-T3A means desktop class I or class II with functional earth with C6 AC inlet
The 4th "*" =-AP or -PP or -SP
-AP (with baby board) stands for Active POE
-PP (no baby board) stands for Passive POE
-SP (no baby board) stands for Simple POE
The last * denote any six character = 0-9 or A-Z or ()[] or – or blank for marketing purposes.

The group and national differences for the CENELEC countries, and the national differences for USA, Canada, Australia, New Zealand, Singapore, China, Japan and Saudi Arabia have been checked.

Date: 11 August, 2023

Signature: